

PVR/DVR

OVERVIEW AND SEARCH



Your universal remote has a RECORD button that enables you to record television shows and events. Using the buttons on your remote, you can pause, rewind and fast-forward PVR/DVR content, giving you total control over your television! Programming is stored for instant recall at any time and until you choose to erase it.

Press RECORD on your remote if you would like to record the show that you are currently watching. The recording will end at the conclusion of the program. Please note: not all channels can be recorded – those that cannot be recorded are listed in gray.

Changing channels while recording – the recording will not be interrupted if you change channels or turn off the television.

Record future programming – select **GUIDE** to enter your interactive program guide and highlight the upcoming show to record. Select **RECORD** and **SAVE** and **EXIT**. Your program will begin recording at the appropriate time and commence automatically when the show has ended. Please note: if you have recorded programming that is normally restricted by parental controls, you will have to enter your Settings PIN and adjust parental controls prior to viewing.

Resume play – you can pause PVR/DVR programming at any time, without affecting the recording. The PVR/DVR will continue to record while the screen is paused. You can resume play when you are ready.

Deleting programming – you may occasionally have to erase content to make room for new records.

1) To delete an individual program from the library, press **DVR RECORDINGS** and then Recorded Programs from the PVR/DVR library. Select the program to delete and press **OK** on the menu, **SAVE** and **EXIT**.

2) To cancel a program scheduled for recurring records, go to the program in the IPG and press **RECORD** and **DELETE**. You will be asked to confirm delete, which will erase all recurring records.

Program conflict resolution – you may run into trouble when selecting a program to record if you have already scheduled a program to be recorded at the same time. Your PVR/DVR will present you with a list of options to fix the problem.

