

Auto-Search Method for backlit and standard Nu-Vision remotes

- Turn the TV on
- Press the 'TV' button in the top left corner of the remote
- Hold the 'SETUP' button below the 'TV' button, until you see the 'TV' button blink two times.
- Enter '991' on the lower keypad
- Press the 'POWER' button at the top of the remote
- Slowly tap the 'CH +' (channel up) button **until** you see the TV turn off (You may stop tapping the 'CH +' button as soon as you see the TV turn off)
- Press the 'POWER' button at the top of the remote; the TV should turn back on (if not, start process over)
- Press the 'SETUP' button to lock the code
- Programming is complete!

